

## Assembly Instructions for the Cross Inlay Kit



This kit is made with Bethlehem Olivewood and Walnut. The cross has been inserted into the recess in the walnut blank already so to secure it in place you'll need to apply thin CA liberally to the cross.

Don't worry about the elastic bands as we'll turn them away later on the lathe. Now we'll glue the brass tube into the blank. Check the fit of the tube as you might have to lightly sand the inside of the blank for a good fit. If you do, use a small dowel wrapped with 100g sandpaper. Use 2-part epoxy to glue in the brass tube. Once the glue has cured sand the ends flush with the brass tube using a belt or disc sander. Don't use a barrel trimmer for this as the wood is now too thin for a barrel trimmer. Now you can mount the blank on the lathe for final turning. Apply whatever finish you're comfortable with as they all work well with the inlay kits.

E-mail me at [kallenshaan@cox.net](mailto:kallenshaan@cox.net) with any thoughts or ideas regarding this or any future inlay kits.