

Basic Assembly Instructions for the Christian Fish Inlay Kit

The fish symbol has been preassembled into the blank to ensure a proper fit. Make sure it is positioned evenly and then secure with thin CA glue.

Insert the brass tube once the CA has cured. If it doesn't fit smoothly, wrap a small dowel with 150G-220G sandpaper and sand the inside of the barrel until the brass tube fits. If you plan on using the Olivewood trim piece you must sand away enough material at the ends of the barrel to allow the BOW trim piece to fit on the brass tube. Glue both pieces on the tube with 2 part epoxy using a small bar clamp or vise to make sure you have a tight fit between the BOW trim piece and the Blackwood body. Once the glue has cured, trim the ends flush with the brass tube and mount on the lathe for turning and finishing.



Send an e-mail with any comments or suggestions about this or any future kits to Ken at:

kallenshaan@cox.net

