

Assembly Instructions for the Basketball Inlay Kit



This kit is made with curly maple and orange dyed Basswood. There are 3 recesses in the maple for the basketballs. Simply position them and secure with the supplied elastic bands. Once all are in position, flood the basketballs with thin CA glue and allow to dry.

Don't worry about the elastic bands as we'll turn them away later on the lathe. Now we'll glue the brass tube into the blank. Check the fit of the tube as you might have to lightly sand the inside of the blank for a good fit. If you do, use a small dowel wrapped with 100g sandpaper. Use 2-part epoxy to glue in the brass tube. Once the glue has cured sand the ends flush with the brass tube using a belt or disc sander. Don't use a barrel trimmer for this. Now you can mount the blank on the lathe for final turning. Although we prefer a CA finish for these, you can apply whatever finish you're comfortable with as they all work well with the inlay kits.

E-mail me at kallenshaan@cox.net with any thoughts or ideas regarding this or any future inlay kits.

